

**WRIGHT TOWNSHIP**  
**Lime Lake/Prattville Sanitary Sewer System**

**WINTERIZATION STEPS**

If the basin will not be used for an extended period, especially during the colder months, proper steps should be taken to ensure uninterrupted use upon restarting the basin.

- Remove the basin cover and check the liquid level.
- Manually pump the station level down to the normal OFF level.
- DO NOT pump the liquid level below the suction at the bottom of the pump.
- With the liquid level at the normal OFF level, add fresh water until the pump turns ON by itself and liquid level is reduced to its normal off LEVEL again.
- Turn the power to the station off in the basin electrical panel.
- Add an appropriate amount of propylene glycol (non-toxic) to the basin liquid to achieve a 50/50 solution mixture. See below for your basin diameter.
  - ❖ 24" diameter will need 20 gallons of antifreeze added to the basin.
- After the antifreeze has been added, turn the power back ON and let the pump run for approximately 10 to 30 seconds to help mix the antifreeze into the pump and discharge. Turn the pump OFF at this time.
- Turn the circuit breaker back to OFF and reinstall the basin cover.

TO REACTIVATE THE BASIN, TURN THE CIRCUIT BREAKER ON AND MANUALLY TURN THE PUMP ON FOR 10 SECONDS.

**Please SAVE these instructions for future reference.**

**Any questions or operational problems please call Jeff at 517-610-4569.**